

**REPLACEMENT PADS  
FOR SHIMANO STYLE V-BRAKES<sup>®</sup>****INSTALLATION:**

1. Remove cotter pin from the V-Brake pad holder.
2. Slide out old pad insert.
3. Replace with AZTEC pad insert.  
The pads are marked "R" and "L" for right and left.
4. Replace the cotter pin and check to be sure the pad is secure in the holder.

*"Shimano" and "V-brake" are registered trademarks of the Shimano Corporation.*

**WARNING:**

Incorrect installation of this product can cause serious injury. Brake pads should be installed by a trained bicycle technician.



Revolution Cycle Works Company  
PO Box 1255  
Charlestown RI, 02813  
Made in Taiwan  
[www.revcycleworks.com](http://www.revcycleworks.com)