

Cable Adjuster Instructions:



When routed out of shifter housing-
make sure the adjuster is completely seated.



When routed into the braze-on cable stops-
Adjuster can be used with or without standard stops.



Lower section of adjuster can be removed
to replace standard plastic adjuster.